Enter the room and touch the Crestron touch panel on the wall to wake it up.



Press the top left light to power on the television/projector

Open a web browser on your computer and type in the network address for the Crestron device



Click on “Start Presenting”



Click on “Windows”



Click on the file that was downloaded



The app will install automatically, and you will be asked for a code to enter for the device to which you are connecting.



Classroom 324
September 25, 2020 | 10:57 AM
Present Using Wireless
Visit: http://10.250.55.57
Code: 8451
Present Using Cables
Connect using cables provided:
CRESTRON


Crestron AirMedia
Not secure | 10.250.55.57/index_airmedia_eth0.html
AirMedia 2
Have the AirMedia Application already?
Enter 10.250.55.57 Code
Enter the code for 10.250.55.57
8451
CANCEL
OK
Don't have the AirMedia Application already?
Download AirMedia Application.
Windows
Don't see the download for your device? Click Here
© 2020 Crestron Electronics, Inc.
All rights reserved.

The image from your device should now be mirrored to the television



Volume can be adjusted from the Crestron touch panel as well.


CRESTRON

To disconnect bring up the control panel shown and click stop. This window will most likely be minimized behind your main application.



To power off the system hold the power icon for 3 seconds.